

Single-axis
BASIC UNIVERSAL



Control units

Single-axis ■ BASIC UNIVERSAL



Regardless of your preferred type of control communication, BASIC UNIVERSAL offers you a wide range of industry-standard interfaces. As a result, this control unit is well suited for a variety of applications – including those in your industry. The correct interface for connecting the IndraDyn motors or other standardized encoders, such as Hiperface®, is already integrated. In addition, this control unit has an empty slot for the connection of another encoder, connection of the analog I/O extension or for the emission of emulated encoder signals.

An additional plug-in MultiMediaCard gives you the option of simple transmission or duplication of your drive parameters. This card can also be used to expand the memory for the motion logic integrated in the drive (firmware option). For an easy start-up use a PC with the Rexroth IndraWorks engineering framework.

Technical data

IndraDrive control units			
Master communication			
Parallel interface		0	
PROFIBUS		0	
SERCOS2		0	
SERCOS III		0	
Multi-Ethernet		0	
CANopen		0	
DeviceNet		0	
Configurations			
Option 1	Geberschnittstelle	•	
Option 2	Zusatzschnittstelle 1	•	
Safety option		•	
Slot for MultiMediaCard		•	
Encoder interfaces			
IndraDyn motors MSK, MKE, MAD and MAF, Hiperface®, 1 Vpp and 5 V TTL		•	
MHD and MKD motors		0	
EnDat 2.1, 1 Vpp and 5 V TTL		0	
Safety options compliant with EN 13849-1 und EN 62061			
Safe Torque Off (Cat. 3 PL e/SIL 3)		0	
Expansions			
Encoder emulation		0	

Single-axis ■ BASIC UNIVERSAL

	T	T -
Analog in-/outputs (extension)		0
Software module		
MultiMediaCard		0
Operation panel		
Standard		•
Cycle times		
Current control	[μs]	125
Velocity control	[µs]	250
Position control	[µs]	500
PWM frequency		
4 kHz		•
Inputs/outputs		
Digital inputs		5
Digital inputs utilizable for touch probes		1
Digital inputs/outputs (user-defined settings)		3
Analog inputs		1
Analog outputs		2
Relay outputs		1
Interfaces		
RS232		•
Control voltage data		
Control Voltage		24 VDC

Basic configurationOption



Bosch Rexroth AG

Electric Drives and Controls
P.O. Box 13 57
97803 Lohr, Germany
Bgm.-Dr.-Nebel-Str. 2
97816 Lohr, Germany
Phone +49 9352-40-0
Fax +49 9352-40-4885

www.boschrexroth.com/electrics

•